



## ETHERNET BLACK BOX SONAR Installation Guide

CHIRP Adapter Cable Wires	Airmar CHIRP Transducer Cable Wires	Functionality
Orange	Blue	High Frequency Pair
Orange & White	Black	
Brown	Blue & White	Low Frequency Pair
Brown & White	Black & White	
Green	Orange	XID
Green & White	White	Temperature
Drain [unshielded wires]	Drain & Brown	Ground/Drain



**NOTE:** Items labeled as High Frequency Pair refer to the higher of two given frequencies. Items labeled as Low Frequency Pair refer to the lower of two given frequencies. For example, a Low & Medium Frequency CHIRP transducer would use the medium frequencies as the High Frequency Pair and the low frequencies as the Low Frequency Pair.